





Waste Bin Rack

The *Waste Bin Rack* supports convenient waste sorting at home. It is mounted on a standard waste bag brace on a cabinet door and enables a *Food Waste Bin* to hang in prime position under the sink next to a residual waste (or other recycling) bag of 20-liter. The *Waste Bin Rack* is symmetrical and can

therefore be rotated to have the *Food Waste Bin* and residual waste bag placed to the right or the left of each other. The rack requires no tools to install and is easy to wash. It is made of recycled plastic and can again be recycled at its end-of-life.



The *Waste Bin Rack* mounted on a standard waste bag brace



Material:

Recycled plastic (rPP)

Cleaning:

Dishwasher safe.

Requirements for

the cupboard door:

The cupboard door must be minimum 60 cm wide.

the waste bag brace:

The brace wire must not be thicker than 6 mm.

the Food Waste Bin:

The rack is designed to fit the *Food Waste Bin* from *Nordic Sorting*.

the residual waste bag:

Standard bags with 20 L capacity.